
PERISCOPIC SEXTANT
CP-188/ASN-6 COMPUTER LATITUDE & LONGITUDE
MI-36 P.A. AMP.
C-1 TRUE AIRSPEED COMPUTER
VIEW LOOKING AFT — MAIN ELECTRONIC RACK
AM-916/ASN-6 ELECTRONIC CONTROL (LNP)
MA-1 TRUE AIRSPEED AMP.
CP-179/APN-82 COMPUTER FREQUENCY TRACKER
ELECTRONIC JUNCTION BOX (REF.)
APN-81 AMP.
AM-758/APN-81 AMP.
RT-274/APN-81 RECEIVER TRAN.
VIEW LOOKING FWD — DOPPLER RACK
C.I. AIRPLANE
STAIR (REF.)
POWER SUPPLY
CODER, TRANSPONDER
PP856
RT-379 REC.-TRANS.
K-4 ATTITUDE GYRO
K-4 ATTITUDE GYRO
J-48 ARC-49 VHF COMM. POWER J. BOX
AUTO-PILOT AMP.
N-1 COMPASS AMP.
R408/ARC-49 VHF COMM. REC.
KY-95
VIEW LOOKING FWD — MAIN ELECTRONIC RACK
AM-300/AIC-10 INTERPHONE AMP.
DY-77/AIC-10 (2 REQ.) INTERPHONE AMP.
BEAM GUID/NCE AMP.
AUTO-PILOT SERVO CONT.
C-1 COMPASS AMP.
N-1 SLAVE CONTROL (REAR)
R-122A/ARN-12 MARKER BEACON REC.
R-322/ARN-18 GLIDE SLOPE RECEIVER
AM( )/APN-71 ALTIMETER AMP. COMP. AM-(XA-79)
AM-( )/APA-87 RENDEZ. RADAR AMP.
SA-( )/APA-87 RENDEZ. RADAR ROTARY SWITCH
KY-65/ARA-26 EMER. CODE -KEYER UNIT
MX-1394/ARC-21 H.F. KEYER ADAPT.
PP-798/ARC-21 H.F. COMM. PWR. SUPPLY
N-1 COMPASS GYRO
FWD.
RT-(XA-125) /APA-87 RENDEZ. RADAR RECEIVER-TRANS.
PP-( )/APA-87 RENDEZ. RADAR POWER SUPPLY
RT-128/ARC-21 H.F. COMM. RECEIVER-TRANS.
R-524/ARR-36 AUX. H.F. REC.
VIEW LOOKING OUTB'D — CTR. FUSE. RACK
APA-87 "J" BOX
JUNCTION BOX